

Article Card

Model 4432



Covers Madras, Semianiline, Nature, Toledo, Fabric

Body part	Foam	Elastic layer	
seat	pocket springs + HR 3038 + HR 3532	flat spring	NO
back	HR 2618 + VP 2542	bonell spring	NO
arm	VP 2542	topline spring	NO
headrest		Nosag Springs	YES
footstol			

Frame construction materials	
solid wood	YES
cheapboard	NO
fiberboard	YES
plywood	YES
steal frame	YES

Colli 1



Manual	
Electric	Pilot

Available functions	
Manual headrest Height adj.	NO
Manual headrest angle adj.	YES
Electrical back angle adj.	YES
Automatic	YES
Manual	NO
Legget-E	YES
Legget-M	NO
Spring Gas	YES
Slide	NO
Lift-Up	YES

MEASUREMENTS:

All measurements can be different about 2-3 cm !

Total Width of chair. [W]
Depending on model, dim. taken from back or between arms.



Size	Width [W]	Height [H]	Depth [D]	Seat depth [SD]	Seat height [SH]	Seat Width [SW]	Lie area
	[cm]	[cm]	[cm]	[cm]	[cm]	[cm]	[m2]
4432 S	79	103	84	52	44	51	
4432 M	79	110	85	53	46	51	
4432 L	82	117	87	56	49	54	

Size	Weight netto	Weight brutto	Volume netto	Volume brutto	Bedclothes Box
	[kg]	[kg]	[m ³]	[m ³]	[m3]
4432 S			0,68	0,73	-
4432 M			0,74	0,79	
4432 L			0,79	0,85	

2016-09-23